



Welcome to Freelap World!

Congratulation in thinking outside the box and providing your team with a tool that will truly maximize their training experience!

> LET'S GET STARTED!

MYFREELAP APP

Freelap timing system is based on a mobile app, so you will need to download the MyFreelap app on your mobile device.

Available on



DOWNLOAD AND INSTALL MYFREELAP APP

DOWNLOAD



Download the MyFreelap app on your mobile device.

CREATE ACCOUNT



Click on "Register" to create your account: enter your email and choose a password

ACTIVATION



Go to your email to confirm your registration to MyFreelap app

LOGIN




Go back to the app and log in.

DONE!



Your app is now ready to go!



➤ SETTING UP YOUR FREELAP TIMING KIT IS FAST AND EASY!

FXCHIP

- ➔ The FxChip turns on automatically when you move, and turns off after 10 minutes of inactivity.
- ➔ It must be attached to the back of the boot, placed vertically, and facing outward.



TX GATE PRO

- ➔ Plant a stake, on the start line. Attach your Tx Gate Pro to your stake using its adjustable bands.
- ➔ The stick should be placed at shins height, parallel to the ground.
- ➔ Get ready on the start line, both shins just in front of the stick. Trigger the start by crossing the gate.



NOTE: No "Power ON" button on the Tx Gate Pro.
This device only turns on a fraction of a second when the stick is activated (very low battery consumption).


TX TRACK PRO

- ➔ To turn on the transmitter, simply press the "ON" central button.
- ➔ Press again the central button to select the desired code : Lap = intermediate transmitter / Finish = finish transmitter. Each press of the central button switches it to the next code. The LED of the selected code lights up.
- ➔ Place the Tx Track Pro on the ground on your course. It is shaped like an arrow. Point the front of the arrow towards the course to draw your virtual finish line or split. Place your transmitter directly on the snow at 3.5 meters max from where athletes pass.



RELAY COACH BLE

- ➔ To turn on the Relay Coach BLE, simply press the "ON" button.
- ➔ Screw the Relay Coach BLE to its tripod (supplied).
- ➔ Place it on the ground, 1 meter behind your finish transmitter (to 10 meters max.)



GET STARTED !

Make sure Bluetooth and location are enabled on your mobile device.

Open **MyFreelap App**.

The first screen you see is your "workout calendar". It displays all past workouts organized by date and time.

Create your new workout by pressing the **+** sign at the top.

Select Relay Coach BLE device type.

Fill in the details, choose a start list and/or a distance list (optional).
And press "START"

You are ready to start your workout and receive timing data !

BATTERY

FxChip : CR 2032 - 2'000 hours of training

Relay Coach BLE : battery Lithium-Ion 3.7V 5Ah LiPo, rechargeable - 80 hours

TX Gate Pro : 2 x AA (LR6 : alkaline batteries) - 15'000 starts

TX Track Pro : battery Lithium-Ion 3.7V 5Ah LiPo, rechargeable - 50 hours

freelap[®]
freedom of timing

**FIND ALL THE INFORMATION ABOUT YOUR FREELAP
PRODUCTS AND OUR DOCUMENTATION ON OUR
WEBSITE : WWW.FREELAP.CH**

For more information, please contact your
distributor. You can find the list on
www.freelap.ch/freelap-contact

FREELAP SA

Av. D.-Jeanrichard 2A - CH-2114 Fleurier - Switzerland
Phone : +41 (0)32 861 52 42 / E-mail : contact@freelap.ch

© Freelap SA 2002 - 2019 - All rights reserved
Freelap is a registered trademark of Freelap SA.